

ENVIROHAZE®

STAIN REMOVER

Quick Tip:

GENERAL DESCRIPTION

ENVIROHAZE® is a water soluble, non-hazardous stain remover. This product is designed to remove the stain (ghost image) from the screen fabric. ENVIROHAZE® works on all types of ink stains, especially plastisol inks, and is safes on all types of fabrics.

ADVANTAGES

- Biodegradable
- Low Odor
- High Flash
- Non-Caustic
- Neutral PH
- Water Soluble
- Mesh Safe

APPLICATION



1. Apply ENVIROHAZE® on both sides of screen.

1022 HP

1000 P.S.I.



A good pressure washer will make your job easier.

for tough stains.

Allow product to

dwell longer, 10 - 15 minutes.



2. Scrub screen with nonabrasive pad or brush. Allow product on to dwell on screen 2 to 5 minutes.



3. High pressure rinse - starting at bottom on the print side of the screen. Reverse screen and high pressure rinse.

Look For More Information on all the Products in the ENVIROLINE® of "Green" Chemistry.













