

MULTI-WASH (APEO / NPEO FREE) Multi-Purpose Screen Wash

General Description

Multi-Wash is a water soluble ink degradent. It is highly effective on plastisol, multi-purpose (solvent based), poster, UV, and vinyl inks. Multi-Wash will protect the fabric from deep stains or ghosting from the image print. This makes it much easier when complete reclamation of the screen is necessary. Multi-Wash can be used in a wide variety of innovative cleaning processes ranging from re-circulation machines, dip tanks, immersion cleaning processes, and automatic reclaiming machines. It can also be applied manually with a scrub pad, spray bottle, or pneumatic pump systems. Multi-Wash is also an excellent plastisol ink haze (ghost) remover and aggressively removes image stains from the mesh.

Advantages

Low Odor

- High Solvency
- High Load Capacity To Reduce Usage
- · High Flash Point / Non-Flammable
- Mesh Safe
- Multiple Applications
- · Does NOT Contain Alkylphenol Ethoxylates (APEO) / Nonylphenol Ethoxylates (NPEO)
- Can Be Diluted Up To 50% With Water

Applications

Always card excessive ink from screen. Use one of the following applications.



At The Sink:

Card excessive ink from the screen. Apply Multi-Wash to ink side of screen. Use non-abrasive scrub brush or pad to agitate ink on both sides of screen. Finally, rinse all residue away using high pressure water.

Haze Remover:

After ink and emulsion has been removed, spray Multi-Wash on both sides of the screen. Scrub screen both sides with a non-abrasive brush or pad. Allow product to dwell a few minutes (depending on severity of stain). High pressure rinse screen working from bottom and moving upwards.

> 4 x 4 Stainless Steel Recirculating Booth

Recirculating Wash:

Card excessive ink from the screen. This product can be continuously recirculated until product becomes too heavily soiled with solids. Used product may be filtered and reused.

Sizes Available:

Quart

Gallon

4 x 1 Gallon

5 Gallon Pail

55 Gallon Drum

Quick Tip:

Always pressure wash screen from the bottom and work upwards.

This will prevent ink from locking back onto the mesh when coming in contact with the rinse water.

